

## What you need for 1x clamp

1x Madrid vertical clamp

1x M18 concrete fixing kit —————→ **KIT INCLUDES:**

1x M18x120mm threaded rod

1x Flat washer

1x Spring washer

1x Nut

1x 6.5mm packer with cutout


**1**

Core drill 20mm holes in concrete slab where spigots will be installed.


Insert M18x120mm threaded rods into core holes and ensure rods are sitting out from the slab 23mm.

(or as required subject to below diagram)

Chemset rods into place.




**NOTE:** Attach a stringline to the concrete surface from where the first clamp is being installed to where the last clamp is being installed and note any variance in slab deviation. Refer to below example for further information.



**2**

Insert offset washer into centre hole on the back of the spigot.  
Discard other offset washers



The offset washer can be rotated inside centre hole to achieve vertical or horizontal adjustment



**3**


Slide spigot with offset washer onto threaded rod and tighten nut over flat washer and spring washer

\*Nut requires 26mm open ended/ring spanner



**4**

Take 6.5mm packer with centre cutout, remove 2x pieces of double sided tape and fit inside throat of spigot over threaded rod



## Tips!

Wedge packers can be used in throat of spigot or behind spigot to achieve tilt adjustment

An extra 4mm bottom packer is included which can be used for vertical adjustment

Handy earthing point located at back of spigot for added safety

Friction plate is recessed for easy glass installation